

## **Quick Start Users Guide**



# Brooklyn Accelerated NAS Gateway Quick Start User Guide

# **Table of Contents**

Chapter 1: Theory of Operation
Chapter 2: Basic Installations 8
2.1 Brooklyn Accelerated NAS Gateway Prerequisites
2.2 Installing the Virtual Machine9
2.3 Brooklyn Accelerated NAS Gateway Disk Requirements 10
2.4 Turning on the Brooklyn Accelerated NAS Gateway for the first time 11
2.5 Configuring the Network for the Virtual Machine12
2.6 Configuring and Mounting a Cloud Bucket16
Chapter 3: Network Configuration
3.1 Modify Network Configuration 22
3.2 Test the Network Configuration 23
Chapter 4: Active Directory
4.1 Adding the Brooklyn Accelerated NAS Gateway to Active Directory
4.2 Configure the Windows Server Security for the Bucket
Chapter 5: Changing the Password 27
5.1 Changing the default password27
Chapter 6: Reboot/Shutdown/Upgrade
6.1 Reboot, Shutdown or Upgrade the system28
Chapter 7: Connecting to the Gateway 29
7.1 Connect over ssh
7.2 Connect over NFS
7.3 Connect over Windows

# SOFTWARE LICENSE AGREEMENT

READ THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT (this "Agreement") CAREFULLY BEFORE USING THIS PRODUCT (the "Product"). THE PRODUCT IS COPYRIGHTED. THE SOFTWARE (AS DEFINED BELOW) IS LICENSED, NOT SOLD. BY USING THIS PRODUCT, YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS AGREEMENT. IF YOU ARE NOT WILLING TO BE BOUND BY THE TERMS OF THIS AGREEMENT, YOU SHOULD IMMEDIATELY RETURN THIS PACKAGE WITH THE PRODUCT UNOPENED AND YOU WILL RECEIVE A REFUND.

1. **License Grant.** BridgeSTOR, LLC ("Licensor") grants to you, and you accept, a non-exclusive license to use the software contained in the Product in machine-readable, object code form only (the "Software") as permitted by this Agreement. The Software may be used only in connection with the Product. You may not assign, sublicense or transfer any of your rights under this Agreement.

2. **Ownership.** You acknowledge Licensor has and will retain exclusive ownership of all proprietary rights to the Software, including all United States and international intellectual property and other rights such as patents, trademarks, and copyrights. You will have no interest in the Software except the right to use it as expressly set forth in this Agreement. You will (a) comply with all copyright, trademark, trade secret, patent, contract or other laws necessary to protect all of Licensor's rights in the Software and (b) not to challenge Licensor's ownership of (or the validity or enforceability of its rights in and to) the Software.

3. **License Fees.** The license fees paid by you are in consideration of the licenses granted under this Agreement. 4. **Term.** This Agreement is effective upon your opening this package and will continue until terminated. You may terminate this Agreement at any time by returning the Product to Licensor. Licensor may terminate this Agreement upon the breach by you of any term of this Agreement. Upon such termination by Licensor, you agree to return the Software and all user documentation to Licensor.

5. **Limited Warranty.** Licensor warrants, for your benefit alone, for a period of 90 days from the date of the commencement of this Agreement (the "Warranty Period") that the Software is free from defects in material and workmanship and that the Product will operate in substantial conformance with the functional specifications described in the user's manual. If a defect in the Software or Product occurs during the Warranty Period, you may return it to Licensor for replacement. This is your sole and exclusive remedy for any breach of representation or warranty by Licensor. EXCEPT FOR THE LIMITED WARRANTY SET FORTH ABOVE, THE PROGRAM AND THE SOFTWARE ARE LICENSED "AS IS" AND LICENSOR DISCLAIMS ANY AND ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY EXPRESS, IMPLIED, OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR GENERAL OR SPECIFIC USE.

6. **Limitation of Liability.** Licensor's cumulative liability to you or any other party for any loss or damages resulting from any claims, demands, actions, or causes of action arising from or relating to this Agreement will not exceed the license fee paid to Licensor for the use of the Software. In no event will Licensor be liable for any indirect, incidental, consequential, special, or exemplary damages or lost profits, even if Licensor has been advised of the possibility of such damages.

7. **Governing Law.** This Agreement will be governed under the laws of the State of Nevada, without regard to conflicts of law principles.

8. **Miscellaneous.** This Agreement contains the entire understanding of the parties with respect to the Software and supersedes any prior oral or proposals, representations, or understandings with respect to such subject matter and may not be modified or superseded, nor may any of its terms or conditions be waived, unless expressly agreed to by the parties in writing. Each provision of this Agreement will be valid and enforceable to the fullest extent permitted by law. If any provision of this Agreement or the application of the provision to any person or circumstance will, to any extent, be invalid or unenforceable, the remainder of this Agreement, or the application of the provision to persons or circumstances other than those as to which it is held invalid or unenforceable, will not be affected by such invalidity or unenforceability, unless the provision or its application is essential to this Agreement. You acknowledge that in the event of a breach of this Agreement, Licensor may suffer irreparable harm and will be entitled to injunctive relief as well as monetary remedies available at law or in equity. The failure of any party to require full performance of any provision of this Agreement will in no way affect the right of such party to enforce such rights at a later time. Headings are for reference purposes only.

# Preface

Welcome to the Brooklyn Accelerated NAS Gateway User Guide. This document provides a comprehensive discussion of the theory of operation, installation, configuration and usage of the Brooklyn Accelerated NAS Gateway and is intended for administrators who will install, operate and maintain the software.

## **Prerequisites**

Before proceeding, you should have a general understanding of the following:

- General networking concepts
- Minimal Linux command line knowledge
- Hypervisor Virtual Machine Management
- Cloud Storage Bucket, Policy and User Management

BridgeSTOR has created a Global File System that transfers files to 3<sup>rd</sup> party Cloud Storage for object availability and access anywhere in the world. To facilitate the Global File System, BridgeSTOR has developed its own Linux file system called CSFS (Cloud Storage File System). The CSFS operating system converts files to objects and transfers them to Cloud Storage. One of CSFS's unique capabilities is the ability to store files in Cloud Storage either in a "Native Object" or "Mangled Object" format. The "Native Object" format allows local files and Cloud Objects to have a 1 to 1 relationship allowing the local file and the Cloud Object be 100% identical. The "Mangled Object" format is a BridgeSTOR proprietary format where a file is broken up into multiple Cloud Objects. The "Mangled Object" format is mandatory when using BridgeSTOR "compression". There are benefits of both modes. The "Native Object" is 100% compatible with other 3<sup>rd</sup> party tools and keeps the 5TB object limit for a file. The "Mangled Object" mode allows higher performance, cost savings and a greater than 5TB file size. Encryption may be used in both modes adding additional security by adding AES-256-bit encryption.

One of the major issues of Cloud Storage is "*how to reduce latency*". Latency is measured by the amount of time it takes for the data to move from the local site to the Cloud. For example, San Diego to AWS in Oregon will be a minimum of 40 milliseconds. Latency is the Storage Administrators worse nightmare when sending data over the wire. The Brooklyn Accelerated NAS Gateway cannot remove the latency, but it can help hide the latency from the End User. Like an HTML proxy cache, HTTP S3 requests are sent into the Brooklyn Accelerated NAS Gateway where the PUT data is written immediately to disk and a transaction is kept locally in the cache. The Brooklyn Accelerated NAS Gateway has multiple background threads that will re-play the transaction file sending

the data directly to the Cloud Storage. Using S3 Multipart upload, each background thread also spawns multiple threads which send the data into the cloud in a fast and efficient manner. When reading a file all GET requests will be read from the Brooklyn Accelerated NAS Gateway first and if the data is not found, the GET request will be pulled from the Cloud Storage updating the local image. These two functions allow the user experience to feel local even if the data is stored 1000's of miles away.

**DO:** Configure Networking using the Linux command line Interface nmtui.

**DO:** Use the BridgeSTOR GUI to configure the Brooklyn Accelerated NAS Gateway host name.

**DO:** Use the BridgeSTOR GUI to add the Brooklyn Accelerated NAS Gateway into Active Directory.

- **DO:** Before Installing, Create Cloud Storage Bucket(s) or Blob(s), assign Bucket Policies and generate authentication keys.
- **DO:** Feel free to download your data from the Native Bucket with any S3 tool.
- **DO NOT:** Delete or add files to a Mangled Bucket as these changes will not be noticed by the BridgeSTOR system. All new files modified files and deleted files should only be modified with BridgeSTOR products.
- **DO:** Change the default root and admin passwords of your Brooklyn Accelerated NAS Gateway before deploying them in a production environment.

## **Document Organization**

<u>Chapter 1, "Theory of Operation"</u> provides an overview of the Brooklyn Accelerated NAS Gateway and how it fits into an overall Global File System.

<u>Chapter 2, "Basic Installation"</u> explains how to install the Brooklyn Accelerated NAS Gateway using an ISO and how to use the BridgeSTOR GUI to configure basic networking.

<u>Chapter 3, "Network Configuration"</u> describes how to modify the Brooklyn Accelerated NAS Gateway networking after installation.

<u>Chapter 4, "Active Directory"</u> explains how insert the Brooklyn Accelerated NAS Gateway into an Active Directory environment.

<u>Chapter 5, "Changing the Password"</u> explains how to change the default Brooklyn Accelerated NAS Gateway GUI password.

Chapter 6, "Reboot and Shutdown" explains how to properly reboot or shutdown the

Brooklyn Accelerated NAS Gateway software.

Note on usage of upper case and typefaces:

- In addition to its normal use, upper case is used for the first letter of words that refer to specific Brooklyn Accelerated NAS Gateway elements; that is, words that have a special meaning, to distinguish them from common usage of the same terms.
- *Italics* is used in the text to distinguish a word or words from surrounding text, such as what the user needs to type into a data entry screen.
- **Bold** typeface is used for emphasis.

# **Customer Support**

The BridgeSTOR support is online only and available 9-5 PST. If you have paid for support a response will be returned with in 4 hours. Please submit a new case in the BridgeSTOR Website at www.bridgestor.com.

## Web Site

For general information about BridgeSTOR and BridgeSTOR products and for all contact information refer to: <u>www.bridgestor.com</u>

# **Copyright Notice**

Coronado Gateway, Brooklyn Accelerated NAS Gateway are trademarks of BridgeSTOR. Other names used in this document are the property of their respective owners.

# **Chapter 1: Theory of Operation**

BridgeSTOR has created a Global File System that allow corporations to store files in 3<sup>rd</sup> party Cloud Storage locations while allowing all corporate locations to securely view and access the files. BridgeSTOR utilize the de-facto standard S3 REST (Representational State Transfer) protocol developed by Amazon as the storage protocol to transfer data between locations.

There are multiple choices for 3<sup>rd</sup> Party Cloud Storage using the REST protocol such as Amazon, Microsoft, Wasabi, RSTOR, Seagate and Backblaze. BridgeSTOR also supports Object storage using the REST Protocol such as Cloudian, EMC, IBM, Netapp and other vendors.

The Brooklyn Accelerated NAS Gateway includes a copy of the BridgeSTOR Coronado NAS Gateway which exports industry standard network protocols SMB and/or NFS allowing for fast and the easy transport of files into the Cloud. The Brooklyn Accelerated NAS Gateway acts as a "*bump in the wire*" storing the most accessed files on local disk and recording each transaction while backend threads replay the transactions and converts the files into objects stored in the cloud. This allows files to appear local, while all files are stored as objects in the Cloud Storage. When files are recovered, the local cache will be checked for the file, if the file exists, it will be returned from the disk cache saving network access and cloud egress charges. All Brooklyn Accelerated NAS Gateway have been designed to run on physical hardware or virtual machines (VM) running in VMware, Microsoft Hyper-V, Oracle Virtual Box or Linux KVM environments.

#### Installing the Brooklyn Accelerated NAS Gateway

The Brooklyn Accelerated NAS Gateway is installed from an industry standard OVA. Once installed on the hypervisor, the network address may be set from the Linux command line. Once set, the BridgeSTOR GUI may be used to modify Networking settings, defining global settings and defining your Bucket Credentials. The Brooklyn Accelerated NAS Gateway also supports ssh for remote management.

#### **Integration with Microsoft Active Directory**

The Coronado NAS Gateway included will support active directory. Active Directory is optional but is supported for enterprise access. Follow the instructions below for installation.

# **Chapter 2: Basic Installations**

For security reasons BridgeSTOR will never create buckets in the Cloud Storage. Before installing, have your Cloud Administrators create your bucket, set bucket policies and create your Access Key and Secret Key. Please review your Cloud Storage documentation on how to perform these tasks.

The sections of this chapter are organized as follows:

- Section 2.1 Brooklyn Accelerated NAS Gateway Prerequisites
- Section 2.2 Installing the Virtual Machine
- Section 2.3 Brooklyn Accelerated NAS Disk Requirements
- Section 2.4 Turning on the Brooklyn Accelerated NAS for the first time
- Section 2.5 Configuring the Network for the Virtual Machine
- Section 2.6 Configuring and Mounting a Cloud Bucket

# 2.1 Brooklyn Accelerated NAS Gateway Prerequisites

The Brooklyn Accelerated NAS Gateway supports virtual machines and may be deployed in VMware, Microsoft Hyper-V, Oracle Virtual Box or Linux KVM environments. The following are required to successfully set up the Brooklyn Accelerated NAS Gateway:

- 1. Network Connective to the Brooklyn Accelerated NAS Gateway.
- 2. Static IP Address, the Internet Gateway Address and DNS Addresses.
- 3. An Active Bucket in the Cloud or Object Storage.
- 4. Valid Access Key and Secret Key for the Bucket.
- 5. Determine if Compression is required.
- 6. Determine if compression is required. Native Access is not allowed in this mode.
- 7. If encryption is required, define a 32-character encryption phrase.
- 8. Determine the Disk Configurations:
  - a. Local Disk for Coronado Ingest Cache if installed. SSD is recommended. This disk should be large enough to handle the largest file copy routine by your system.
  - b. Local Disk for Brooklyn Accelerated NAS Gateway Metadata. SSD is recommended, 1TB will support approximately 70 million files.
  - c. Local Disk for Brooklyn Accelerated NAS Gateway. This could be SSD or spinning disk. This disk is where all cached data resides. This disk maybe as large as required.

## 2.2 Installing the Virtual Machine

The Brooklyn Accelerated NAS Gateway ships as a CentOS 7 image inside an OVA. Most hypervisor environments should easily recognize this format and easily import the image. If it does not, you may do the following:

1) An OVA image is nothing more than a compressed OVF image. Use the tar command below to decompress the image.

tar -xvf Brooklyn.ova

2) Once uncompressed, you will see the following virtual disk files.

brooklyn-disk1.vmdk

brooklyn-disk2.vmdk brooklyn-disk3.vmdk brooklyn-disk4.vmdk brooklyn-file1.nvram brooklyn.mf brooklyn.ovf

- 3) Use these files to install as an OVF for your hypervisor.
- 4) If your hypervisor still not cannot install with the OVF, then you will have to create the virtual machine manually. Use brooklyn-disk1.vmdk as your boot disk

At this point, both images should be ready to be booted.

## 2.3 Brooklyn Accelerated NAS Gateway Disk Requirements

The Brooklyn Accelerated NAS Gateway is extremely flexible on its disk requirements. The system ships with a 128GB boot disk and should be large enough for booting. The included Coronado Gateways requires one disk for a temporary ingest cache. The ingest disk installed is 1TB and is used when NFS or SMB protocols write or read files to and from the Gateway. Once files are closed, the files are flushed out of the ingest cache. BridgeSTOR recommends the ingest drive should be on SSD or flash and be large enough to support the maximum file data sent to the Gateway at any time. If the drive is too small, users will receive disk full errors.

The Brooklyn Accelerated NAS Gateway requires an additional two disks. One for the Metadata and the second for the cached files. The Metadata drive should be sized based on the projected number of files that may managed by the system. BridgeSTOR estimates about 70 million files per Terabyte of disk. BridgeSTOR ships with this drive set at 512GB and should be placed on SSD for optimal performance. The file cache disk ships as 1TB and may be placed on SSD or spinning disk. The cache should be sized based on the number of files that need to be accessed locally. The Brooklyn Accelerated NAS Gateway will always check this disk first for files. If the file does not exist, the Brooklyn Accelerate NAS Gateway will pull the file from the Cloud Storage. So obviously performance will be much faster if the data is local. However, if the disk is sized too large than you will be thrashing as data is erased and re-written. This will affect your performance.

All the BridgeSTOR default disks may be resized by the hypervisor. After modification, reboot the system and the new configuration will automatically recognized and the disks will be expanded to the new size.

# **2.4 Turning on the Brooklyn Accelerated NAS Gateway for the first time**

The BridgeSTOR Accelerated NAS Gateway ships as a CentOS 7 image and may be managed by a web-based GUI. Once your machine is turned on, you will be presented a Centos 7 login screen.



The Brooklyn Accelerated NAS Gateway ships with two internal users; one user for the Centos 7 system called "root", and another for BridgeSTOR administration called "admin". Refer to the table below for usernames, passwords and descriptions.

Username	Password	Description
root	Bstor1234	Super user login access for setting networking and general management tasks
admin	Bstor1234	Web based credentials for BridgeSTOR configuration and as a default login for SMB or NFS

# 2.5 Configuring the Network for the Virtual Machine

If you installed from a Virtual Machine, you must first give the system a Network Address. If you installed from an ISO you may skip this step and move on to 2.8. After logging in as root run the following command.

#### nmtui

The following screen should appear.



Select "Edit a connection" and press return. This will allow you to modify the network addresses of the network connection. The following screen will appear.



The ethernet name is highlight in red. Your name may be different depending on the system. Use the tab key to move to the "Edit" button. The current selection will always be in red. Press the Return key and the following screen should open.



Use the tab key again to move to <show> next to "IPv4 CONFIGURATION <Disabled>. Press the enter key to enter you network configuration. Below is an example of a completed entry for the screen.



First, change the field next to "IPV4 CONFIGURATION" from Disabled to Manual. This will turn on the network port. Next change the "Addresses" field, in this example we gave the address of 10.10.30.254 with a netmask of 255.255.255.0. The netmask is configured by the /24 or the CIDR. If you are not using 255.255.255.0 then replace the /24 with /xx for your correct CIDR. Finally change your network Gateway and DNS Servers. If you will be configuring Active Directory the first DNS entry must be the Active Directory DNS server. The second may be any DNS server that you prefer. Once everything is selected tab to the <OK> button and hit return.

You will return the previous menu. Use the tab key and select the <back> button and press return. This will bring you back to the first screen of nmtui. Use the tab key to select "Edit a connection". Then use the down arrow to select "Quit". This will exit you from the program.

At this point, reboot the system and login. Use ping or any other network tool to verify that you network connection is valid. Please do not continue with 2.8 until you have a valid network connection.

## 2.6 Configuring and Mounting a Cloud Bucket

At this point, the server or virtual machine has been configured. The remaining install portion of the installation may be done with the BridgeSTOR GUI. The system will be installing SSL Certificates in the background. This can take up to 20 minutes. You may review the status by logging into the system and running the following command.

systemctl status bstor\_gui



The line "waiting on Diffie helman pem" will occur. When this changes to "Start bstor\_gui", the process has completed, and you may enter the GUI.

Use your favorite browser and enter in your IP Address for the Brooklyn Accelerated NAS Gateway. The system uses a self-signed certificate so you may see a warning about entering the site. Just acknowledge the certificate and continue to the site. You will be prompted with a login screen.



Enter the default password "Bstor1234". This will allow you to enter into the system. Once logged in, you should see the following screen.

Brooklyn NAS Edge Cache									Help	
Version:2.0.1.7					Cloud Share Credentials				Wed	Oct 06,2021 8:43 PM
Cloud Share Cred	lentials	Network Config	guration	Active Directory	Change Password	Change Password Reboot/Shutdown/Upgrade Logout				
	Select	Mount F	Point	Bucket Name		Access Key		Mo	ounted	
	0	/C00	)						no	
	0	/C01	1						no	
	0	/C02	2						no	
	0	/C03	3					no		

Notice on the mount point screen. You are allowed up to 4 Cloud mount points, all with their own Bucket Name, Access Key and Secret Key. For now, let's concentrate on installing a single bucket. Additional buckets may be set up following the same instructions.

#### a) Configure your Bucket Parameters

Click on the radio button for Mount Point /c00 and select "edit credentials". The "edit credentials" screen allows you to define a bucket and up to 3 additional routing or mirrored Cloud Storage Buckets. Each additional bucket requires it's own endpoint with additional access keys and secret keys. Once the data is sent to the primary bucket, the data will be mirrored to the other defined buckets. For this example, we will not be using mirrored buckets. The following screen should be displayed.

Version:2.0.1	-		Cradantic							
Version:2.0.1.	Network Configuration	Active Directory	Locout	8:46 PM						
	Network Configuration	Active Directory	Change Password	Reboolonataowinopyrade	Logour					
			Bucket Setti	ıgs						
		Bucket Name:								
		Bucket Endpoint: s3.am	azonaws.com	Use SSL: 🔽						
		Access Key:								
	De	stination Address: s3 am	azonaws.com	Start: 443 End: 443						
		NFS Enabled:								
		SMB Enabled:								
			apply							
			Router 1 Sett	ngs						
		Bucket Name:								
		Bucket Endpoint: \$3.am	azonaws.com	Use SSL: 🗹						
		Access Key:								
	De	Secret Key:	97009WE COM	Start: 443 End: 443						
	56	Sunation Address, polan	azonawa.com							
			арру							
			Router 2 Sett	ngs						
		Bucket Name:								
		Bucket Endpoint: s3.am	azonaws.com	Use SSL: 🗹						
		Access Key:								
	De	Secret Key:	7000000 0000	Start: 442 Ead: 442						
	De	sunation Address. ps.am	apply	Start. 445 End. 445						
			Router 3 Sett	nas						
		Bucket Name:								
		Access Key	azonaws.com	Use SSL: M						
		Secret Key:								
	0-			Start: 442 Ead: 442						

#### b) Install Your Bucket Credentials

To complete a proper bucket installation, each bucket requires 5 items.

- 1) **Bucket Name**. This is the bucket name of your Cloud or Object Storage. This bucket name must exist in your Cloud or Object Storage. For security purposes, BridgeSTOR will not create this bucket.
- 2) **Bucket Endpoint**. This is the URL address of the bucket location. For example.

s3.amazon.aws.com points to Amazon east coast.

If you are using a region other than Amazon east coast enter the region of the bucket in the URL. For example,

Brooklyn Accelerated NAS Gateway User Guide v4.1.0

s3-us-west-2.amazon.aws.com is the Oregon region.

For other providers, use their URL defined in their documentation. After defining the URL, please select if you would like to use https:// by selected the "Use SSL" box. If this is not clicked, the system will use the http protocol.

- 3) **Access Key**. Enter the Access Key for the bucket defined in your Cloud Storage for Microsoft, enter the "Storage Account" name.
- 4) **Secret Key**. Enter the Secret Key assigned to the bucket. For Microsoft enter the Access key assigned to the storage account.
- 5) **Destination Address**. This is the URL or IP Address of the bucket. Most o the time it will be the same address as #2 above. For Object Storage, it will be a local address of the Object Storage head. A port range is also available for use. If supported by an Object Storage system, the BridgeSTOR system will use a Round Robin approach to multiple Storage Nodes for redundancy and performance.
- 6) **NFS Enabled**. Allow NFS connectivity to this bucket. After the system has been mounted, users may mount an NFS mountpoint to the bucket.
- 7) **SMB Enabled**. Allow SMB connectivity to this bucket. After the system has been mounted, users may map a drive letter to this bucket.

Once all the data has been entered, press the "apply" button. This will not only save the data to the system but will verify if the data entered is correct with the Cloud or Object Storage bucket. If an error occurs, please check your input and try again.

#### c) Define your Global Parameters for the Bucket.

The first time a bucket has been setup, it will require Global Parameters before mounting the system. If you are setting up a second Coronado Gateway or a second Brooklyn Accelerated NAS Gateway you may skip this step as it should have been setup the first time.

There are 5 global settings per bucket. Native and the Encryption Phrase may never be changed without destroying your bucket. The following screen displays the global parameters:

Bridge STO We Make Cloud Storag	Bro	ooklyn NAS Ee	Help		
Version:2.0.1.7	Bucket Signature				Wed Oct 06,2021 8:47 PM
Cloud Share Credentials	etwork Configuration	Active Directory			

- Native. First determine if the bucket should be in a Native Format or a Mangled Format. Remember, the Native Format is a one-to-one representation of a file to an object. If compression or encryption is selected, you have no choice but to use the Mangled Format. Check the box if you want to use Native Format and uncheck the box if you want Mangled Format.
- 2) Shareable. This mode is used if the Bucket will be shared between multiple sites. Shareable is required to be set for a global file system. Site sharing will slightly slow up the system. For example, when a file is opened, the system will have to confirm that the local cache has the latest file by making a call to the Cloud or Object Storage. If it does not, the system will erase the cached version replacing it with current version. If the bucket will not be shared by any other location, than leave the box unchecked.
- 3) **Compression.** If compression is required for this Bucket check this box. Compression may be turned off later if it is no longer required. Compression can save Cloud Storage by compressing the data before sending the data to the Cloud or Object Storage. However, the compression ratio is data dependent as some files like Microsoft Office files are already compressed and will not compress any further.
- 4) **Maximum Size in TB.** When displaying in Windows, the system is required to give a size for the User. BridgeSTOR allows you to enter the size in this field. Human behavior is funny, if you enter a large size, they users may think they can fill it up. So, make a reasonable size here. There is no right or wrong to the selection. This field may be changed later.
- 5) **Encryption Phrase.** BridgeSTOR allows multiple encryption keys per Bucket based on the Bucket Path. This phrase will set the "/" Path for the bucket. If encryption is required, enter a phrase up to 32 characters to be used as a key. For security purposes, BridgeSTOR will not save this key. A SHA

representation is saved in the cloud to confirm the key is accurate, but the key will only be saved in the Gateway. **REMEMBER THE PHRASE**. If you lose the phrase, BridgeSTOR cannot help you recover your data

Once your satisfied with your selections, press "apply". The data will be written to the Bucket and saved for other Gateway's in the future.

#### d) Mounting the Bucket

Before the bucket may be accessed, it must be mounted by the system. Return to the main menu of the system. Click the radio button of the /c00 Mount Point and then press the "mount" button.

# **Chapter 3: Network Configuration**

The Brooklyn Accelerated NAS Gateway requires proper networking to operate. After installation if you need to change the network configuration the BridgeSTOR GUI allows modification to the IP Address information.

## **3.1 Modify Network Configuration.**

At this point all networking should be functional. Login to the Brooklyn Accelerated NAS Gateway with your web browser by entering the IP address. Select the *"Network Configuration"* from the main menu. The following screen will appear:

Bridge ST(	<b>DR</b> Storage Accessible	Bro	ookiyn NAS E	Help		
Version:2.0.1.	7		Networ	k Configuration		Wed Oct 06,2021 8:49 PM
Cloud Share Credentials	Network Configuration	Active Directory	Change Password	Reboot/Shutdown/Upgrade	Logout	
			Ping Test			
		Ping IP Addr	ess: apply	]		

- 1. **Editing the IP Address Settings**. These series of input allow the IP Settings to be modified. Once the edits have been completed, press enter to update the system. If you want to cancel at any time press another option from the main menu and the information will not be saved.
  - a) **Host Name.** Enter the host name of the system. The Host Name should be a unique name for the Brooklyn Accelerated NAS Gateway.
  - b) **IP Address**. This field sets the static IP Address of the Brooklyn Accelerated NAS Gateway.

- c) **Netmask.** Enter the netmask for the IP Address. The name may be up to 8 characters and may not contain spaces. If mirrored pairs are not required, this field may be left blank.
- d) Gateway Address. The Internet Gateway IP address.
- e) **Domain DNS Address.** The address to locate domain names. If Active Directory is required, then this first address must point to the Active Directory DNS server.
- f) **Secondary DNS Address.** This field allows a failover DNS address in case the first address fails.

Press "apply" and the system will save the parameters and return to the Brooklyn Accelerated NAS Gateway Menu.

## **3.2 Test the Network Configuration**

This screen includes a "Ping Test" screen which allows you to test the network. Type a Network Address in the "Ping IP Address" field and press "enter". This will attempt to contact the server entered.



# **Chapter 4: Active Directory**

In a Windows Environment, the Brooklyn Accelerated NAS Gateway may insert itself into an Active Directory Environment. The Host Name entered in Chapter 3 will be inserted into Active Directory as a Windows Server. In order for Active Directory to be installed successfully, the Primary DNS name in Chapter 3 must point to the Active Directory DNS server. An Active Directory Administrative password is required for the screen

# **4.1 Adding the Brooklyn Accelerated NAS Gateway to Active** Directory

Select "Active Directory" from the main menu. The following menu will appear.

Bridge ST	OR Storage Accessible		Bro	Help			
Version:2.0.1.7 Active Directory In					ectory Integration		Wed Oct 06,2021 8:50 PM
Cloud Share Credentials	Network Config	uration	Active Directory	Change Password	Reboot/Shutdown/Upgrade	Logout	
•							

- a) **Active Directory Doman Name.** Enter the full Windows Domain Name for your environment
- b) **Administrator Name.** Enter the username of the Windows Domain Administrator.
- c) **Administrator Password.** Enter the password of the Windows Domain Administrator.

After entering these fields, press "join domain" and the system will take a few seconds before giving you a response.

## **4.2 Configure the Windows Server Security for the Bucket**

When configuring Samba shares for Windows, the best practice is to configure share permissions on a newly created share. Applying permissions after data exists is very time consuming. All file permissions must be posted to the backend object store.

The end goal is to create a single Active Directory compatible Windows share, which all users may map to as a drive letter. The top-level functional folders should be defined as categories or groups. For example, eng, mktg, finance, etc. Users will only see folders for directories that they have permissions to view. There are no write permissions to the top-level of the share.

- a) Login to a Windows Server as a Domain Admin.
- b) Open the MMC (start->run->fsmgmt.msc) and set to the Access Point
- c) Click the "Action->Connect to another computer" and connect to the Brooklyn Accelerated NAS Gateway. Once connected open the share->s3 properties page. For Example, \\100.10.10.90
- d) The configuration described in this document does not use SHARE level permissions. SHARE level permissions should be left at the defaults of "everyone" and Full control. Proceed to step "f" if share level permissions are not required.
- e) Our recommendation is to manage folder access by using Security/(File System) permissions exclusively. This is accomplished by leaving the share level permissions at their Samba default settings of Full Control for the Everyone group and proceeding to step "f" as seen below.

If your environment requires SHARE level permissions, proceed to "Setting Share Level Permissions" below before moving to step "f".

If setting SHARES, perform the following:

- 1) Add "Domain Admins" with full access.
- 2) Add "Domain Users" with change and read access.
- 3) Remove "Everyone"
- f) Set Security (file system) top level permissions.
  - 1) Add "Domain Admins" with full access.
  - 2) Add "Domain Users" with read only access on "this folder only"
  - 3) Advanced button->Change Permissions button->Add Button
  - 4) Select Apply to: *This folder only*
  - 5) Click Allow box for: a. Travers folder / execute file

- a) List folder / read data
- b) Read attributes
- c) Read extended attributes
- d) Read permissions
- 6) Remove "Everyone"
- g) Create the functional folders and assign permissions
  - 1) Map the share as the Domain Admin <u>\\IP\s3</u>
  - 2) Create a functional group "top level folder" and add security permissions.
    - a) Typical *Write* permissions include:
      - I. Modify, Read & Execute, List folder contents, Read, Write
      - II. Note Full is excluded which excludes modifying permissions.
    - b) Typical *Read* permissions include
      - I. Read & Execute, List folder contents, Read

# **Chapter 5: Changing the Password**

The BridgeSTOR GUI allows you to change the admin GUI password. This is original set to "admin" from the default install.

#### 5.1 Changing the default password.

Select "Change Password" from the main menu. The following menu will appear.

Bridge STOR We Make Cloud Storage Accessible			Brooklyn NAS Edge Cache					Help
Version:2.0.1	.7		Change Brooklyn Password				Wed Oct 06,2021 8:51 PM	
Cloud Share Credentials	Network Confi	guration	Active Directory	Change Password	Reboot/Shutdown/Upgrade	Logout		
			N.	Old Password:				
			Rety	New Password:				
				apply				

- a) **Old Password.** Enter the current password for the system.
- b) New Password. Enter a new password.
- c) **Retype New Password.** Re-enter the password to confirm accuracy.

After entering these fields, press "apply" and the system will take a few seconds before giving you a response.

# Chapter 6: Reboot/Shutdown/Upgrade

The BridgeSTOR GUI allows you to reboot or shutdown the system.

## 6.1 Reboot, Shutdown or Upgrade the system.

Select "Reboot/Shutdown" from the main menu. The following menu will appear.

Bridge ST	<b>OR</b> <sup>®</sup> Storage Accessible		Brooklyn NAS Edge Cache					Help
Version:2.0.1	.7		Reboot or shutdown					Wed Oct 06,2021 8:51 PM
Cloud Share Credentials	Network Config	guration	Active Directory	Change Password	Reboot/Shutdown/Upgrade	Logout		
Select and Option								
			reboot	shutdown upgrad	de upgrade status			

- a) **Reboot.** Click "reboot" to reboot the system.
- b) **Shutdown.** Click "Shutdown" to shut down the system.
- c) **Upgrade.** Click "upgrade" to upgrade the system. Wait a few minutes and the press the "upgrade status" button and it will show if the upgrade has been completed.

The system will take a few seconds before giving you a responding.

# **Chapter 7: Connecting to the Gateway**

The BridgeSTOR Gateway allows users to connect over NFS, SSH or Windows. The gateway defaults with a user called admin, unless Active Directory is used, use admin and the default password.

#### 7.1 Connect over ssh

Use whatever ssh tool that you prefer. Simply supply the BridgeSTOR Gateway address to your ssh program and use the "root" login name with the "Bstor1234" to connect. It's advised that you change the root password once logged into the system.

#### 7.2 Connect over NFS

The BridgeSTOR Gateway supports both NFS 3 and NFS 4. From your NFS machine, use your normal NFS mount command and create a mount point to the NFS gateway. The mountpoint will be based on the bucket that you have mounted. From the main GUI screen, you will see /c00, /c01, /c02, /c03 next to your bucket. This is the nfs mount point. For example, the first bucket would use /c00 and mount to the BridgeSTOR Gateway as:

mount -t nfs 10.10.30.254:/c00 /mnt/nfs

#### 7.3 Connect over Windows

The BridgeSTOR Gateway supports Windows connective using the Samba protocol allowing Windows users to connect to the BridgeSTOR Gateway over a standard windows share. Users may login with either the BridgeSTOR Gateway "admin" user or if the BridgeSTOR Gateway has connected with Active Directory an active directory user.

Map a network drive the BridgeSTOR Gateway. For example: From File Explorer, right click on the "This PC" and use the "Map network drive" and to login into the Gateway. Select the drive letter and enter the share name. The share name is the BridgeSTOR Gateway address followed by the share name. The Windows share name is based on the bucket from the main GUI screen. You will see /c00 /c01 /c02 or /c03 next to your bucket. The name of the first bucket is /c00 so the share name would be \\10.10.30.254\c00. Select "Connect using a different credential" and then press Finish and you will be prompted to enter the username and password. Enter the username and password and press "OK". If correct, the drive will show up in File Explorer.